

## PDT 4 Button remote control Transmitter Coding Instructions

### Rollertec Control Panels – 2005 – current

- Using an existing transmitter (that is already coded in), press and hold the 'grey' button – the LED on the control unit will start to flash Yellow slowly. Keep the button pressed down until the LED flashes quickly
- Release the 'grey' button and press the top 'green' button. The LED should change from flashing Yellow to flashing Green. Now release the 'green' button on this transmitter
- On the new transmitter (that needs to be coded in), press the top 'green' button for a second and release. The flashing LED should remain lit continuously for second or so – this indicates coding has been successful.
- Repeat above steps for each new transmitter

Please note: Programming mode automatically stops after 30 seconds of no activity