



How to code a new Rallye 40.685MHZ transmitter to match an existing one

- 1) Remove the back from the new transmitter and an existing working transmitter.
- 2) On the old transmitter read the code from the set of ten switches noting which switches are 'on'
- 3) Replicate this code on the switches of the new transmitter.
- 4) Replace backs of transmitters, they are now ready for use.

Instructions to code 2-button transmitters for Rallye 40.685MHZ radio

WARNING KEEP HANDS AWAY FROM ALL MOVING PARTS

- 1) Remove light cover.
- 2) Identify "LERNE" button mounted on circuit board.
- 3) Remove all transmitter back covers and re-set dip switches to new positions (all transmitters matching).
- 4) Push "LERNE" button on circuit board and one transmitter simultaneously (light should come on) then release 'LERNE' button only.
- 5) Keeping push button on transmitter down (light should flash) when light stops flashing release.
- 6) Push transmitter button and operator will start.
- 7) Replace transmitter back covers and operator light cover.
- 8) Second button can then be coded into the second operator following steps 4-6

Instructions to code in transmitters for PICO 868MHZ plug in radio receiver

- 1) Remove light cover
- 2) Identify the plug in radio receiver (small circuit board with GREEN / RED LED)
- 3) Push the 'LEARN' button on the receiver for 1 second – the LED will light up
- 4) Push the desired button on the hand transmitter – the LED will go out
- 5) Push the button on the hand transmitter – the LED will flash on and off for 5 seconds
Transmitter has been coded in, replace light cover

Manual release in event of power cut or malfunctions of operator.

With the door in closed position, pull sharply on the red handle above centre of door, it should click and de-latch. While pulling cable, push bottom of door slightly open and release the handle. The door can now be opened fully. Note if this has not been used recently or has not been lubricated it may appear very stiff.

Reconnecting door to operator.

Place door in half open position and push either remote control handset or internal push-button and operator will run for a few seconds and self connect. The door will now work normally.

[If you have any problems, please contact us by email](#)